



Walter Mueller AG

*Operating Instructions*

***Speed controllers  
530 series***

---

These operating instructions are valid for controllers with the nameplate designation

531

532

533

534

Controller type

Edition of: 03/2018

revised: --/----

## ***How touse this manual ...***

To locate information on specific topics, simply refer to the table of contents at the beginning and to the index at the end of this manual.

The manual uses a series of different symbols to provide quick reference and to highlight important items.

This symbol refers to items of information intended to facilitate operation.



Notes which should be observed to avoid possible damage to or destruction of equipment.



Notes which should be observed to avoid health risks to the operating personnel.





# Safety and application notes for drive controllers

(according to: Low Voltage Directive 2014/35/EU)

## 1. General

During operation, drive controllers may have, according to their type of protection, live, bare, in some cases also movable or rotating parts as well as hot surfaces.

Unauthorized removal of the required cover, inappropriate use, incorrect installation or operation, creates the risk of severe personal injury or damage to material assets.

Further information can be obtained from the documentation.

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out **by qualified, skilled personnel** (Low Voltage Directive 2014/35/EU, EMC Directive 2014/30/EU, Machinery Directive 2006/42/EG and national regulations for the prevention of accidents must be observed).

Qualified skilled personnel according to this basic safety information are persons who are familiar with the erection, assembly, commissioning, and operation of the product and who have the qualifications necessary for their occupation.

## 2. Application as directed

Drive controllers are components which are designed for installation into electrical systems or machinery.

When installing into machines, commissioning of the drive controllers (i.e. the starting of operation as directed) is prohibited until it is proven that the machine corresponds to the regulations of the EC directive 2006/42/EG (Machinery Directive); EN 60204 must be observed.

Commissioning (i.e. starting of operation as directed) is only allowed when there is compliance with the EMC Directive (2014/30/EU).

The drive controllers meet the requirements of the Low Voltage Directive 2014/35/EU. The harmonized standards of the EN 50178 together with EN 60439-1 and EN 60146 are applicable to drive controllers.

The technical data and information about the connection conditions must be obtained from the nameplate and must be observed in all cases.

## 3. Transport, storage

Notes for transport, storage and appropriate handling must be observed.

Climatic conditions must be observed according to EN 50178.

#### 4. Erection

The devices must be erected and cooled according to the regulations of the corresponding documentation.

The drive controllers must be protected from inappropriate loads. Particularly during transport and handling, components must not be bent and/or insulation distances must not be modified. Touching of electronic components and contacts must be avoided.

Drive controllers contain electrostatically sensitive components which can easily be damaged by inappropriate handling. Electrical components must not be damaged or destroyed mechanically (health risks are possible!).

#### 5. Electrical connection

When working on live drive controllers the valid national regulations for the prevention of accidents (e.g. VBG 4) must be observed.

The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, PE connection). More detailed information is included in the documentation.

Notes concerning the installation in compliance with EMC - like screening, grounding, arrangement of filters and laying of cables - are included in the documentation of the drive controllers. These notes must also be observed in all cases for drive controllers with the CE mark. The compliance with the required limit values demanded by the EMC legislation is the responsibility of the manufacturer of the system or machine.

#### 6. Operation

Systems where drive controllers are installed must be equipped, if necessary, with additional monitoring and protective devices according to the valid safety regulations, e.g. law on technical tools, regulations for the prevention of accidents, etc. Modifications of the drive controllers and the operating software are prohibited.

After disconnecting the drive controllers from the supply voltage live parts of the controller and power connections must not be touched immediately because of possibly charged capacitors. For this, observe the corresponding labels on the drive controllers.

During operation, all covers and doors must be closed.

#### 7. Maintenance and servicing

The manufacturer's documentation must be observed.

**This safety information must be preserved!**

**The product specific safety and application notes in these operating instructions must also be observed!**

# Contents

<b>1</b>	<b>Features of the 530 series of controllers</b>	<b>5</b>
<b>2</b>	<b>Technical data</b>	<b>6</b>
2.1	Controller-specific data	6
2.2	Dimensions	7
2.3	Scope of supply	8
2.4	Application as directed	8
<b>3</b>	<b>Accessories</b>	<b>9</b>
<b>4</b>	<b>Installation</b>	<b>11</b>
4.1	Installation	11
4.2	Connection	11
4.2.1	Installation corresponding to EMC	14
4.2.2	CE-typical drive system	15
4.3	Connecting voltage	18
4.4	Replacing the fuses	19
4.5	Connection diagram	20
<b>5</b>	<b>Setting</b>	<b>22</b>
5.1	Selection of the current range for type 534	22
5.2	Setting the current limit	23
5.3	Speed setting	23
<b>6</b>	<b>Operating modes</b>	<b>25</b>
6.1	Switching operation	25
6.1.1	Controller enable	25
6.1.2	Controller inhibit	25
6.2	Electrodynamic braking	26
6.3	Reversing	28
	<b>Index</b>	<b>29</b>

# 1 Features of the 530 series of controllers

The 530 series of controllers series comprises 4 half-controlled single-quadrant controllers with output powers from 0.36 kW to 2 kW for the operation of DC shunt or permanent magnet motors.

- Compact single-board controllers for space-saving installation on a mounting plate or DIN rail 35 x 7.5 mm
- Easy connection through screwless, vibration-proof plug and socket connectors
- Protective cover prevents accidental contact of live components
- Operation with tacho or armature voltage feedback with "I x R compensation"
- Operational integrity even under mains voltage fluctuations and short-term mains failure because of static and dynamic voltage monitoring
- Interference immunity from bad mains wave-form because of synchronizing filter and channel separation of the firing pulses
- Compliance with the EC directive for the design of a CE-conform drive system

## 2 Technical data


### 2.1 Controller-specific data

Controller		531	532	533	534	
Output power	$P_{el}$ [W]	360		720	1360	2040
Mains frequency	$f$ [Hz]	50...60				
Mains voltage	$U_{L1, N}$ [V]	190...265 (100...132 with solder link)				
Armature current (can be changed for 534)	$I_{Amax}$ [A]	2		4	8	12
Armature voltage for $V_{L1, N} = 230$ V	$V_A$ [V]	180		180	180	170
Field voltage	$V_F$ [V]	$0.9 \times U_{L1, N}$				
Max. field current	$I_{Fmax}$ [A]	0.3		0.6	1.5	
Perm. form factor	$F_{Fmax}$	1.4		1.4	1.6	1.2
I · R compensation	$R_A$ [ $\Omega$ ]	0...20		0...10	0...5	0...2.5
Rated master voltage	$V_{LN}$ [V]	10				
Rated tachometer voltage	$V_{TN}$ [V]	10...120				
Acceleration time	$T_i$ [s]	1...10				
Min. speed	$n_{min}$ [rpm]	0...0.25				
Max. speed	$n_{max}$ [rpm]	0.75...1				
Ambient temperature during operation	$T_a$ [ $^{\circ}$ C]	0...45				
Fuse type		FF6.3 / 250V 491541363		FF8 / 250V 491541380	FF20 / 250 V k.A.	
Weight	$m$ [kg]	0.4			1.2	
Operating instructions type		116160100-052				



## 2.2 Dimensions

### Type 531




1) Jumper "BR1", "BR2" (change 230 V / 120 V)

2) Jumper "BR3" ( $n_{max}$  setting)

Type	a [mm]	b [mm]	c [mm]	d [mm]
531	35	160	150	100

### Types 532 and 533

### Type 534



1) Jumper "BR1", "BR2" (change 230 V / 120 V)

2) Jumper "BR3" ( $n_{max}$  setting)

Type	a [mm]	b [mm]	c [mm]	d [mm]	e [mm]	f [mm]	g [mm]	h [mm]	Ø [mm]
532, 532	120	109	95	7	22.5	45	127	-	4.5
534	120	109	95	7	88	100	150	6	4.5

## 2.3 Scope of supply

The scope of supply includes:


- the controller 53x
- the operating instructions
- the set-value potentiometer 10 k $\Omega$
- plug-in terminals

## 2.4 Application as directed

- The controllers of the types 53x are electrical equipment for installation into control cabinets of electrical systems or machinery.
- The controllers of the types 53x are designed as components for the control of speed-variable drives with separately-excited DC motors or for the assembly with other components to form a machine or system.
- Drive systems with drive controllers 53x which are installed according to the definition of a CE-typical drive system (see chapter 4.2.2), correspond to the EC EMC Directive and the standards mentioned below.  
CE-typical drive systems are
  - suitable for the operation on public and non-public mains and
  - provided for industrial applications.
- Because of the ground potential reference of the RFI filters, the CE-typical drive system which is described is not suitable for the connection to IT mains (mains without ground potential reference).
- The drive controllers are not domestic appliances, but they are designed for drive systems for commercial use.
- The controllers of the types 53x themselves are not machines according to the EC Machinery Directive. The final function is only determined when integrated into the machine construction of the user.
- The user must consider measures in his machine construction which limit the consequences in case of malfunction or failure of the drive controller (increase of the motor speed or sudden motor stop) so that hazards for persons or material assets cannot be caused, such as:
  - further independent equipment for the monitoring of safety-relevant variables (speed, travel, end positions, etc.)
  - electrical or non-electrical protective equipment (latching or mechanical blocking)
  - measures covering the complete system

### 3 Accessories

Type	531	532	533	534
Armature choke	Suitable types depend on motor type			
Mains choke Type	–	–	–	2.5 mH, 18 A
RFI filter Type	k.A.			k.A.
Spring kit for DIN rail 15 mm Type	–	k.A.	–	k.A.
Set-value pot. type				10k $\Omega$ / 1W <sub>lin.</sub> TW1103KA



## 4 Installation

### 4.1 Installation

The chassis-type controller is to be installed in a vertical position, with the terminals at the bottom, to ensure sufficient cooling and air circulation. The ambient temperature must not exceed +45°C.

Unwanted voltages fed back from the controllers to the supply mains are reduced by the connection of mains chokes and RFI filters. The components allocated to type 53x are listed in chapter 3 "Accessories".

### 4.2 Connection

- The controllers contain electrostatically sensitive components. Prior to assembly and servicing the personnel must be free of electrostatic charges. Discharging is possible by touching the PE fixing screw or another grounded metal part in the control cabinet.
- If you use residual current devices:
  - The controllers have an internal mains rectifier. After a short-circuit to frame a DC fault current may prevent the tripping of the residual current device. Therefore, take additional measures like zeroing or use universal current e.l.c.b.
  - Observe for the dimensioning of the release current of e.l.c.b. that capacitive compensating currents of the cable screens and RFI filters occurring during normal operation may cause false tripping.

- The plug connector is suitable for the connection of solid wire or single or multi-strand conductors of cross-sections between 0.14 and 2.5 mm<sup>2</sup>. The length of the free wire should be 10 mm. It is not necessary to use ferrules.

Before removing the protective cover, switch-off the controller and remove the connectors.



#### **Warning**

**All controller terminals carry mains potential. It is therefore necessary that all input and output signals required for the control of the controller are, electrically, safely separated by measures outside the controller and have another protection against direct contact (double basic insulation).**

**When using the supplied set-value potentiometer the mechanical fixing must have an additional PE connection and the connections must be insulated and covered.**

Prior to commissioning make sure that there is no earth fault in the connecting cables. The protective conductor must only be connected to the PE connection (6.3-mm spade connector). PE or ground connections to any other terminals cause a controller failure.

Screen motor cables A, B, I and K as well as the control cables. The screen must be connected at both ends to the central PE connection. The control cables must not be longer than 10 m. Check the voltage rating of the screened cable.

To ensure that the screening is effective, it should not be opened or interrupted. It should also be laid as close as possible at the cable ends. Connect the screening of the motor cables to PE in the motor terminal box.

If the cable between RFI filter and controller is longer than 200 mm, use screened mains cables. The ground chassis connection should have as low a resistance and as large a surface as possible.

Type 53x can be used for operation with armature voltage or tacho feedback (see chapter 4.5 "Connecting diagram").

In case of armature voltage control with "I x R compensation" insert a jumper between terminal 2 and terminal 4.

**Caution!**

**At terminals 2/4 and 3/4 only the feedback system used must be connected.**

For master voltage operation remove the set-value potentiometer and apply the master voltage across terminal 7 (-) and terminal 8 (+).

**Caution!**

**The master voltage must be free of mains and ground potential. Several controllers can only be operated from a master voltage when they are electrically isolated.**



Note for the connection of controller and motor

WMAG controller		Motor (acc. to DIN 42017 / VDE 0530 part 8)		
Function	Terminal	Terminal	other designations	Motor type
Armature voltage	+ A	1B1	A1	DC motor uncompensated with commutating pole winding
	- B	2B2	B2, A2	
Excitation voltage	+ I	F1	E1	
	- K	F2	E2	
Armature voltage	+ A	1C1	A1	DC motor compensated with commutating pole winding
	- B	C2	C2	
Excitation voltage	+ I	F1	E1	
	- K	F2	E2	
Armature voltage	+ A	A1		Permanent magnet motor
	- B	A2		
DC tacho	+ 3	2A1		
	- 4	2A2		
AC tacho with rectification	+ 3	3A1		
	- 4	3A2		

## 4.2.1 Installation corresponding to EMC

- Controllers cannot be operated on their own. The EMC of controllers on their own cannot be tested. Only the integration of the controllers into a drive system allows a test whether the objectives of the EC EMC Directive are met and whether the device are in compliance with the law about the electromagnetic compatibility of equipment.
- If you observe the following measures you can assume that EMC problems caused by the drive system will not arise during the operation of the machine and the EMC Directive and the EMC law are satisfied.
- For any other installation, e.g.
  - use of unshielded cables,
  - use of collective RFI filters instead of the allocated RFI filters,
  - omission of mains chokesthe machine or system must be tested whether it is compliance with the EC EMC Directive and the EMC limit values are considered.
- **The compliance with the EMC Directive in the machine application is the responsibility of the user.**



## 4.2.2 CE-typical drive system

### Components of a CE-typical drive system

System components	Specification
Controller	Controller of the types 531 to 534
RFI filter	Data and allocation see chapter 3 "Accessories"
Mains choke	Data and allocation see chapter 3 "Accessories"
Armature and field cable	Screened power cable with tinned E-CU braid with 85 % optical coverage. Tested maximum length: 50 m
Mains cable between RFI filter and mains choke and between mains choke and controller	As from cable length of 200 mm: screened power cable with tinned E-CU braid with 85 % optical coverage.
Control cables	Screened signal cable type LIYCY
Motor	DC motor with separate excitation Lenze series GFQ, GFR or similar

#### Note:

Controller, RFI filter, and mains choke are located on one mounting plate.

### Installation of the CE typical drive system

The electromagnetic compatibility of a drive system depends on the type and accuracy of the installation.

Take special care with

- filters
- screening
- grounding

#### Filters

- Only use the RFI filters and mains chokes allocated to the controllers (see chapter 3 "Accessories").
  - RFI filters reduce non-permissible high-frequency interferences to a permissible value.
  - Mains chokes reduce low-frequency interference which depends primarily on the motor cables and their length.  
For motor cables which are longer than 50 m additional measures are required.

#### Screening


- Screen all cables from and to the controller.
- Make sure that motor cables are separated from signal and mains cables when laying the cables.
- Avoid a common terminal board for mains input and motor output.
- The cables must be laid as close as possible to the reference potential. Dangling cables are like antennas.

## Grounding

- Ground all conductive metal components (controllers, RFI filters, mains chokes) by suitable cables from a central grounding point (PE bar).
- Observe the minimum cross-sections prescribed in the safety information. However, for EMC the surface of the contact is important and not the cross-section.


## Assembly

- Make a contact from controller, RFI filter, and mains chokes to the grounded mounting plate with as large a surface as possible. Zinc-coated mounting plates allow long-lasting contacts. For painted plates the paint of the mounting plates must be removed in all cases.
- If you use several mounting plates:
  - Make a conductive connection of the mounting plates with as large a surface as possible (e.g. using copper bands).
- Connect the screen of the armature and field cable to the mounting plate with as large a surface as possible:
  - Recommendation: Make the large-surface connection of the screens to the mounting plate with earthing clamps on bare metal mounting surfaces.



- If there are contactors, motor protection switches, or terminals in the armature cable:
  - Contact of the screens of the connected cables to each other and to the mounting plate with as large a surface as possible.
- In the terminal box, connect the screen of the motor to PE:
  - Metal cable glands at the motor terminal box ensure a large-surface connection of the screen to the motor housing.
- If the total length of the mains cable between RFI filter and mains chokes and controller exceeds 200 mm:
  - Screen mains cables
  - Connect the screen of the mains cables to the mounting plate with as large a surface as possible.
- Connect the screen of the control cables to the mounting plate with as large a surface as possible.

## Part of the CE-typical drive system which is located on the mounting plate



1) The mains choke is only necessary for type 534.


### 4.3 Connecting voltage

As a standard, the controller is factory-set for the operation on a mains voltage from 190 to 265 V  $\pm 0$  %. For a mains voltage from 100 to 132 V  $\pm 0$  % replace jumper "BR1" with "BR2".



#### Caution!

**This modification must only be carried out by qualified skilled personnel when no voltage is applied. After replacing the jumpers the protective cover must be reassembled.**



## 4.4 Replacing the fuses

The fuses protect the controller from non-permissible operating conditions. After the operation of such a protective function, the controller and the system must be checked for further faults before replacing the fuses.

For the replacement of the fuses remove the protective cover and disconnect the connectors.

### Caution!

**Removal of the protective cover and the replacement of the fuses must only be carried out by qualified skilled personnel when no voltage is applied.**


Defective fuses must only be replaced by the prescribed type (see chapter 2.1 "Controller-specific data").

The protective cover must be attached again after the fuses are replaced.



## 4.5 Connection diagram

### Type 531



1) see chapter 4.3 "Connecting voltage"

2) standard component


### Explanations

①	Coded part
②	Jumper "BR 3"
③	Actual value tachogenerator
④	Controller enable
⑤	Master voltage

### Note:

If the signals must be changed over via relays, use suitable relay contacts (e.g. gold-plated contacts).

## Types 532, 533, 534



1) see chapter 4.3 "Connecting voltage"

2) standard component

3) only required for type 534

### Explanations

①	Jumper "BR3"
②	6.3-mm spade connector
③	Controller enable
④	Master voltage
⑤	Actual value tachogenerator

### Note:


If the signals must be changed over via relays, use suitable relay contacts (e.g. gold-plated contacts).

## 5 Setting

Turn trimmers "I x R", " $n_{max}$ ", " $n_{min}$ ", " $T_i$ " and set-value potentiometer fully counterclockwise. Trimmer " $I_{max}$ " is factory set to rated controller current. The current range selector for type 534 is factory set to 8 A.

### 5.1 Selection of the current range for type 534

The current range of type 534 can be set to 12 A by switching off the controller and moving selector **S1** from position 8 A to position 12 A.



#### Caution!

The current range must only be set by qualified skilled personnel when no voltage is applied.



## 5.2 Setting the current limit

Setting the current limit is only required if the maximum output current must be reduced.

- Turn trimmer " $I_{max}$ " fully counterclockwise and " $n_{min}$ " fully clockwise.
- Connect a moving coil ammeter into the armature circuit to measure the current.
- Disconnect the field or stall the motor (observe the current capacity of the motor during standstill!).
- For armature voltage control, remove jumper between terminals 2 and 4.
- Connect mains, close switch "RFR". Turn " $I_{max}$ " clockwise to set the armature current.
- To calculate the value to be set, divide the rated armature current (see nameplate) by the form factor ( $I_{AN} / FF$ ).  
The permissible rated controller current must not be exceeded.
- Then disconnect the mains, turn " $n_{min}$ " fully counterclockwise, connect the field and for armature voltage control, reconnect the jumper between terminals 2 and 4.

## 5.3 Speed setting

- For **armature voltage control with "I x R compensation"** insert jumper between terminals 2 and 4 as shown in the connecting diagram.
- For **speed control with tach feedback** remove jumper between terminals 2 and 4. Connect the tachogenerator (see connecting diagram). For rated tach voltages > 40 V the setting range of the " $n_{max}$ " trimmer can be improved by removing jumper "BR3" (see chapter 4.5 "Connecting diagram" and chapter 2.2 "Dimensions").

### Caution!

**The jumper "BR3" must only be removed by qualified skilled personnel when no voltage is applied.**

**In case of uncontrolled acceleration of the motor during speed setting, immediately open switch "RFR". In this case, either the tachogenerator feedback is missing or has incorrect polarity.**



After checking and correcting the wiring, commissioning can be started again.

- Switch on the mains and close switch "RFR". Turn the set-value potentiometer to maximum or set the master voltage to  $V_{LN} = 10 \text{ V}$ . Turn trimmer " $n_{\max}$ " clockwise until the desired maximum motor speed is achieved.
- Turn set-value potentiometer fully counterclockwise or set master voltage to 0 V. Turn trimmer " $n_{\min}$ " clockwise until the desired minimum motor speed is achieved.
- If the minimum speed is to be zero, turn trimmer " $n_{\min}$ " counterclockwise until the motor has just stopped running in order to avoid dead movement of the set-value potentiometer in the low speed range. Check the setting of the maximum speed because  $n_{\min}$  and  $n_{\max}$  influence on each other.
- For **armature voltage control with "I x R compensation"** the motor speed loss under load is compensated by turning trimmer "I x R" clockwise. Set trimmer "I x R" at low speed until the minimum speed change between idle running and rated load is achieved. Then, check the setting at higher speed and the maximum speed setting.


## 6 Operating modes

### 6.1 Switching operation

#### 6.1.1 Controller enable

If switch "RFR" is closed, the controller is enabled.

If the switch "controller enable" (RFR) is open, the firing pulses are blocked and the controller is reset.




**Note:**

Only use low-current contacts for the switching of signal cables  
(20 V / 1 mA)

#### 6.1.2 Controller inhibit

The function "RSP", i.e.g the inhibiting of the controller with a normally-open contact is possible using the following connection.

When "RSP" (controller inhibit) is closed, the firing pulses are blocked and the controller is reset.



**Note:**

Only use low-current contacts for the switching of signal cables  
(20 V / 1 mA)

## 6.2 Electrodynamic braking

If the field is excited, the induced armature current is used for braking the motor. Before connecting the brake resistor, the controller is inhibited. The timer relay must be set such that the braking contactor only opens after the motor has stopped.

### Dimensioning of the brake resistor $R_B$

Neglecting the armature feedback for a required initial braking torque  $M_{Ba}$ , the initial braking current  $I_{ABa}$  results in:

$$I_{ABa} = I_{AN} \cdot \frac{M_{Ba}}{M_N}$$

$I_{AN}$  = Rated armature current  
 $M_N$  = Rated torque  
 $M_{Ba}$  = Initial braking torque

The braking resistor  $R_B$  is calculated as follows:

$$R_B = \frac{U_{Aa} \cdot \eta_A^2}{I_{ABa}}$$

$U_{Aa}$  = Armature voltage in the motor mode  
 $I_{ABa}$  = Initial braking current  
 $\eta_A$  = Armature efficiency

$$\eta_A = \frac{2\pi \cdot M \cdot n}{U_A \cdot I_A}$$

$U_A$  = Armature voltage  
 $I_A$  = Armature current  
 $M$  = Torque  
 $n$  = Speed


The size of the brake resistor depends on the braking energy of the drive and the number of brakings. The braking current should not be more than twice the rated armature current and should not exceed the maximum starting current.

**To limit the switching voltage peaks, a zinc oxide varistor (R<sub>U</sub>) must be connected in parallel to the controller output.**

For long motor cables (> 50 m) or motors which are connected in parallel, it may be necessary to use an interference suppression module (see chapter 3 "Accessories")



Braking circuit:



- 1) Interference suppression module
- 2) Mains choke is only required for type 534

### Explanations

K1, K2, K5	Relay
S1	On
S2	Stop


## 6.3 Reversing

Reversing is obtained by changing the armature polarity. The motor is electro-dynamically braked to standstill. The braking time must be set at the timer relay such that the motor is safely at standstill before the armature is reversed (for dimensioning of the brake resistor see chapter 6.2 "Electrodynamic braking").

**To limit the switching voltage peaks, a zinc oxide varistor ( $R_U$ ) must be connected in parallel to the controller output.**

For long motor cables (> 50 m) or motors which are connected in parallel, it may be necessary to use an interference suppression module (see chapter 3 "Accessories")

Reversing circuit:



- 1) Interference suppression module
- 2) Mains choke is only required for type 534

### Explanations

K5, K6, K7	Relay
S2	CW rotation
S3	CCW rotation

# Index

## A

- Accessories 9
- Application
  - as directed 8

## B

- Braking
  - Electrodynamic 26

## C

- Controller features 5
- Controller-specific data 6

## E

- EC declaration of conformity**
  - CE-typical drive system** 15

## I

- Installation 11
  - Connecting diagram 20
  - Connecting voltage 18
  - Connection 11
  - Installation 11

## O

- Operating modes 25
  - Controller enable 25
  - Controller inhibit 25
  - Electrodynamic braking 26
  - Reversing 28

## R

- Replacing the fuses 19
- Reversing 28

## S

- Safety information 2
- Scope of supply 8
- Setting
  - Select current range 22
  - Setting the current limit 23
  - Speed 23



© 03/2018



Walter Müller AG  
Russikerstrasse 37  
CH-8320 Fehraltorf  
Switzerland



+41 (0)44 956 / 26 26



wmag@wmag.ch



www.wmag.ch

116160100-052a

